

# Candlewic Company

## KIT-9

### Palm Wax Votive & Pillar Kit

#### **This Kit Includes:**

- 5 lbs. Feathering Palm Wax (PALM-3)
- 3” Ball Mold (DSM-13)
- 4 – 15 hour Votive Molds (M-63)
- 6 ft. wicking (RRD-40)
- 15 Votive Wicks (RRD-29)
- 5 Color Chips (red, yellow, blue, green, & brown)
- 1 ounce each of Red Apple Peel (US-4), Lemongrass Sage (US-60), Maybell (US-42), Rainforest Blossom (US-63), Cinnabon (S-85)

#### **You Will Also Need:**

- Melting Pot or container to melt wax in
- Thermometer – any cooking or candy thermometer will work
- Covered work surface

#### **What You Will Do:**

Place 1 lb. of the wax into the melting pot and put the melting pot into a large pot of water that has been brought to a boil. This will create a double boiler for you to heat your wax. Never heat wax directly on a heat source. Let the wax melt completely. Once the wax is liquid you will want to add your color chip. One color chip is sufficient to color 1 lb. of the wax to a very rich color. After the color is added, you then want to pour the 1 ounce bottle of scent into the melted wax and stir the wax mixture very well.

Take the cut wicking and thread it through the hole in the pillar mold. Tie a loose knot in the wicking at the bottom of the mold and then cover the wick hole with mold seal. Stretch the wicking to the top of the mold and tie it around the wicking needle. Make sure that the wax is between 190 and 200 degrees and then pour the wax mixture into the mold, filling it to the top. You will have extra wax leftover that you can

use to fill the votive molds. After the votive mold is filled take one of the Votive Prewick Assemblies and place it into the center of the mold and let the candle solidify. Allow the candles to cool completely before removing them from the molds.

Notes: This wax is very temperature sensitive. You can achieve a variety of feathering effects by pouring the wax at different temperatures. Be careful never to pour wax into a polycarbonate mold if it is over 200 degrees, you can damage the mold. If you have difficulty demolding your candles, try placing the mold in the refrigerator for 20 minutes first.

~ When burning your candles please be sure to always follow safety precautions ~

- Do not burn a candle for more than 4 hours at a time
- Always burn candles in an appropriate holder
- Allow candle to cool before relighting

- Keep wick centered and trimmed to ¼”
- Do not burn candles in a draft
- NEVER LEAVE A BURNING CANDLE UNATTENDED

The Candlewic Company  
3765 Old Easton Road  
Doylestown, PA 18901  
800-368-3352  
[www.candlewic.com](http://www.candlewic.com)